



	Skype	X-lite	Mizu Softphone
1	Speaker Phone	Speaker Phone	-----
2	Hold	Line1	-----
3	-----	Line 2	-----
4	Answer Key	Answer/Call Key	Answer/Call Key
5	Scroll Up/Down	Scroll Up/Down	Scroll Up/Down
6	End/Cancel Key	End/Cancel Key	End/Cancel Key
7	Skype Dial	SkypeDial/Redial	Skype Dial
8	Clear	Clear	Clear
9	Show/Hide SysTray Icon	Show/Hide SysTray Icon	Show/Hide SysTray Icon
10	Mute Microphone	Mute Microphone	-----
11	Volume +/-	Volume +/-	Volume +/-